
ROBERTS GORDON°

Blackheat® HE U-Tube and Linear

Low-intensity Radiant Heaters for Poultry



Minimal maintenance costs due to protection of internal burner components against dust and water

Increased energy efficiency from heating floors and objects, rather than the air

Longer heater life provided by durable components such as heat treated aluminised tube


BURNER BOX

Even floor temperatures for optimal chick performance and growth from infrared energy



Quality in Any Language™

ROBERTS GORDON



*Based on Gross Calorific Value

Clearances to Combustibles ** [mm]

Model HE15UT HE20UT HE25UT HE30UT HE35UT HE40UT HE45UT HE50UT Model

Horizontal	150	150	150	150	150	150	200	200	ţ	150	150	150	150	150	150	200	200
	890	970	970	1020	1170	1220	1270	1380		890	970	970	1020	1170	1220	1280	1330
←B → C →	1580	1730	1730	1910	1980	2050	2110	2210	L→B→I I←D→ ↓	1570	1650	1650	1780	1930	1970	2010	2080
•	760	940	940	1000	1090	1150	1200	1300		890	970	970	1020	1170	1220	1280	1330
45° ↑	200	200	200	200	200	200	200	200	t	200	200	200	250	250	275	300	300
	200	200	200	200	200	200	200	200		200	200	200	200	200	200	200	200
	1500	1650	1650	1860	1960	2040	2110	2160		1500	1660	1660	1860	1960	2030	2110	2160
	1070	1170	1170	1320	1550	1620	1680	1780		1370	1520	1520	1630	1750	1820	1880	2000
	1070	1170	1170	1320	1550	1620	1680	1780		1370	1520	1520	1630	1750	1820	1880	2000

**Clearances B, C and D can be reduced by 50% for locations 7 m or more downstream of the burner. For other mounting options and associated clearances, complete installation, operation and service criteria, please see the current issue of the Installation, Operation and Service Manual.

Installation Code and Annual Inspections:

All installations and service of ROBERTS GORDON[®] products must be performed by a contractor qualified in the installation and service of products sold and supplied by Roberts-Gordon and conform to all requirements set forth in the ROBERTS GORDON[®] manuals and all applicable governmental authorities pertaining to the installation, service and operation of the equipment. To help facilitate optimum performance and safety, Roberts-Gordon recommends that a qualified contractor annually inspect your ROBERTS GORDON[®] products and perform service where necessary, using only ROBERTS GORDON[®] replacement parts.

Further Information: Applications, engineering and detailed guidance on systems design, installation and product performance is available through ROBERTS GORDON® representatives. Please contact us for any further information you may require, including the Installation, Operation and Service Manual.

Roberts Gordon Europe Limited

Oxford Street Bilston, West Midlands WV14 7EG UK Telephone: +44(0) 1902 494425 Fax: +44(0) 1902 403200 Service Telephone: +44(0) 1902 498733 Service Fax: +44(0) 1902 401464 E-mail: uksales@rg-inc.com E-mail: export@rg-inc.com www.rg-inc.com **Corporate Headquarters (USA)** Roberts-Gordon, LLC Telephone: +1 716.852.4400 Fax: +1 716.852.0854

All rights reserved. No part of this work covered by the copyrights herein may be reproduced or copied in any form or by any means – graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems – without written permission of Roberts-Gordon.

HE15ST HE20ST HE25ST HE30ST HE35ST HE40ST HE45ST HE50ST